









NÁVOD NA MONTÁŽ



2 Osoby



Starostlivosť!


Čistíte len suchou alebo vlhkou handričkou. Nepoužívajte žiadne abrazívne čistiace prostriedky!

Maximálne zaťaženie policí v kg:


Dĺžka	Hrúbka			
	mm	15	18	22
0<400				
401<600	40	40	40	
601<800	24			
801<1000	15	30		

- A1** $\phi 8 \times 36$ x34
- B5** x6
- B4** x6
- G5** #15 x6
- B1** 7x50 x10
- I1** $\phi 2$ x10
- S1** x14
- B3** x10
- UL** L-224 x4
- UP6** 4x30 x10
- D10** 3,5x13 x8
- D1** 3,5x25 x5
- E2** H0 x4
- I11** x5
- EK2** 6,3x13 x8
- G2** S-4 x1
- G8** L-826 x1
- H6** L-278mm x4
- D27** 6x8 x8
- D18** M4x9mm x4
- G1** Leim x1
- E1** Kr0 x4


1




2




3




4





5



7




6



(B11) 7x50 x4

(I1) $\phi 2$ x4










Model:

DERBY

Číslo modelu: **36-260-__**

Strana **5** Z: **6**



10**Možnosť regulácie**

a) Regulácia medzery:
Povoľte skrutku "A", povolením skrutky "B" nastavíte medzeru, dotiahnite skrutku "A".

b) Regulácia hĺbky:
Povoľte skrutku "A" (1 otočka) nastavíte hĺbku, dotiahnite skrutku "A".

c) Regulácia výšky:
Povoľte skrutku "C" (1 otočka) nastavíte výšku dverí a dotiahnite skrutku "C".