



# NARVIK B-2

HALMAR Sp. z o.o.  
 ul. Centralnego Okręgu Przemysłowego 2, 37-450 Stalowa Wola, POLSKA / POLAND  
 tel. +48 15 843 28 10, fax: +48 15 842 19 57, e-mail: office@halmar.com.pl

<p>A</p> <p>2pcs</p>	<p>B</p> <p>1pc</p>	<p>C</p> <p>1pc</p>
<p>D</p> <p>1pc</p>	<p>E</p> <p>2pcs</p>	<p>F</p> <p>1pc</p>
<p>G</p> <p>4pcs</p>	<p>H</p> <p>4pcs</p>	<p>I</p> <p>2pcs</p>
<p>J</p> <p>2pcs</p>	<p>K</p> <p>6. 3x40 12pcs</p>	<p>L</p> <p>M6x30 8pcs</p>
<p>M</p> <p>M6x27 4pcs</p>	<p>N</p> <p>M6 4pcs</p>	<p>O</p> <p>2pcs</p>
<p>P</p> <p>2pcs</p>	<p>Q</p> <p>1pc</p>	<p>R</p> <p>1pc</p>

**1**  
 Ax2  
 Gx4  
 Hx4  
 Bx1  
 O<sub>x</sub>2  
 Lx4

**x2**

**x1**

max. 30 kg

**2**  
 Lx4

**3**  
 Fx1  
 Mx4  
 Nx4

**4**  
 Dx1  
 Jx2

**5**  
 Cx1  
 Ex2  
 Kx4

**6**  
 Ix2

**7**  
 Kx8  
 Px2