


















KOMO

CR-1801

Montážný návod



 A 1ks	 B 1ks	 C 1ks
 D 1ks	 E 1ks	 F 1ks
 G 3ks	 H 1ks	
 I 2ks	 J 12ks	
 K 1ks	 L 6ks	 M 6ks