















SANTANA 120







001	1200	600	16	1	1/1
002	1178	557	16	1	1/1
003	194	194	16	1	1/1
004	378	598	16	1	1/1
005	384	598	20	1	1/1
				1	1/1








<p>x2 p39 Ø 4x20mm</p> 	<p>x5 r1 Ø 15x12mm</p> 	<p>x5 r16</p> 	<p>x3 s2</p> 
<p>x3 p9 Ø 4x30mm</p> 	<p>x2 e1 Ø 7x50mm</p> 	<p>x5 f1 Ø 8x30mm</p> 	<p>x2 k1</p> 
<p>x1 z1</p> 			






1





2





3





4








5




6





SANTANA 155



001	1248	245	16	1	1/1
002	1550	245	16	1	1/1
003	228	253	16	1	1/1
				1	1/1

**x8
e1**

Ø 7x50mm




**x8
f1**


Ø 8x30mm



**x2
s2**



**x3
g2**



**x2
r16**



**x6
e19**

Ø6x9 mm



**x2
r1**



**x3
e2**

Ø6.3x13 mm



**x1
z1**




**x3
f3**

Ø10x50 mm




**x3
p17**


Ø 5x60 mm




1




2




3








4






















SANTANA 2K/155






001	1550	420	16	1	1/2
002	512	286	16	2	1/2
003	275	402	16	1	1/2
004	1549	402	16	1	1/2
005	494	354	16	1	1/2
006	275	402	16	1	1/2
007	275	382	16	1	1/2
008	275	382	16	1	1/2
009	1534	293	2,5	1	1/2
					1/2



<p>x6 l2</p> 	<p>x4 a144</p> 	<p>x4 b119</p> 	<p>x2 c412.048</p> 
<p>x4 d1</p> 	<p>x8 e1</p> <p>Ø 7x50mm</p> 	<p>x20 f1</p> <p>Ø 8x30mm</p> 	<p>x1 f3</p> <p>Ø 10x50mm</p> 
<p>x2 m27</p> 	<p>x1 n14</p> 	<p>x1 p17</p> <p>Ø 6x50mm</p> 	<p>x36 p25</p> <p>Ø 3.5x16mm</p> 
<p>x4 p9</p> <p>Ø 4x30mm</p> 	<p>x8 r1</p> <p>Ø 15x12mm</p> 	<p>x8 r16</p> 	<p>x5 k311.054</p> 
<p>x5 s2</p> 	<p>x1 z1</p> 		










1








2





3




4





5





6






7






8






9





10





11




























Ø10


SANTANA 2D3S






001	1800	420	16	1	2/2
002	755	513	16	1	1/2
003	755	513	16	1	1/2
004	743	402	16	1	1/2
005	743	402	16	1	1/2
006	513	286	16	2	1/2
007	513	177	16	1	1/2
008	1799	402	16	1	2/2
009	743	382	16	1	2/2
010	743	382	16	1	2/2
011	743	382	16	1	2/2
012	496	382	16	2	1/2
013	232	382	16	2	2/2
014	437	200	16	2	2/2
015	350	200	16	2	2/2
016	350	200	16	2	2/2
017	437	120	16	1	2/2
018	350	120	16	1	2/2
019	350	120	16	1	2/2
020	761	511	2,5	2	1/2
021	761	511	2,5	1	1/2
022	761	250	2,5	1	1/2
023	352	455	2,5	3	1/2
accessories				1	1/2




 x12 l2	 x2 a144	 x2 a145	 x4 b119
 x5 c412.048	 x16 d1	 x20 e1 Ø7x50	 x44 f1 Ø8x30
 x2 f3 Ø10x50	 x6 k311.054	 x2 n14	 x6 n260.01.007
 x2 p17 Ø6x50	 x90 p25 Ø3.5x16	 x10 p9 Ø4x30	 x20 r1
 x20 r16	 x19 s2	 x16 s4	 x3 lb L-350
 x1 z1			









1




2




3




4




5




6






7




8






9






10




11




12




13




14






15






16






17





18






SANTANA 1W1D



001	1163	405	16	1	2/4
002	901	405	16	1	1/4
003	901	405	16	1	1/4
004	1193	639	16	1	4/4
007	271	405	16	1	2/4
008	271	405	16	1	2/4
009	254	286	16	1	2/4
010	254	286	16	1	2/4
011	1163	385	16	1	2/4
012	621	405	16	1	1/4
013	620	385	16	2	1/4
014	621	254	16	1	2/4
015	232	385	16	2	1/4
016	232	370	16	1	1/4
018	618	355	5	1	3/4
019	1181	318	2,5	1	2/4
020	1181	318	2,5	1	2/4
021	1181	249	2,5	1	2/4
				1	1/4

x14 l2 	x8 a144 	x8 b119 	x2 c412.048 
x4 d1 	x4 d3 	x6 e1 Ø7x50 	x36 f1 Ø8x30 
x1 f3 Ø10x50 	x4 k311.054 	x1 n14 	x6 n260.01.007 
x2 o1 	x1 p17 Ø6x50 	x2 p39 Ø4x20 	x54 p25 Ø3.5x16 
x2 p9 Ø4x30 	x38 r1 	x8 r10 	x22 r16 
x30 s2 	x1 z1 		



2


Diagram illustrating the assembly of the side panels (013 and 015) onto the base. The panels are secured using screws (f1) and rivets (r1). A warning indicates that the distance between screws should not exceed 10 mm.

3


Diagram illustrating the assembly of a rectangular frame structure. The main assembly shows the frame with various components labeled: **b119** (corner brackets), **r16** (corner fasteners), **d3** (corner fasteners), and **f1** (corner fasteners). A circular callout labeled **001** indicates a specific assembly point. Two inset diagrams provide detailed views of the assembly process:

- The left inset shows the installation of component **b119** onto the frame using a screwdriver.
- The right inset shows the installation of component **d3** onto the frame using a screwdriver.


4




5




6




7




8





9




10




11




12






13





14







15





16







SANTANA 1S




001	1534	858	16	1	1/2
002	902	405	16	1	1/2
003	897	286	16	1	1/2
004	334	60	16	1	1/2
005	1131	362	16	1	1/2
006	856	405	16	1	1/2
007	858	384	16	1	1/2
008	896	363	16	1	1/2
009	542	361	16	2	1/2
011	799	200	16	1	1/2
012	338	361	16	1	1/2
013	350	200	16	1	1/2
014	350	200	16	1	1/2
015	272	405	22	1	1/2
016	272	405	22	1	1/2
017	352	817	2,5	1	1/2
018	274	874	2,5	1	1/2
019	1538	404	20	2	2/2
				1	1/2
				1	2/2


<p>x2 l2</p> 	<p>x1 c421.048</p> 	<p>x27 e1 Ø7x50</p> 	<p>x34 f1 Ø8x30</p> 
<p>x1 f3 Ø10x50</p> 	<p>4x k311.054</p> 	<p>x1 n14</p> 	<p>x1 p17 Ø6x50</p> 
<p>x10 p18/1 Ø3.5x20</p> 	<p>x32 p25 Ø3.5x16</p> 	<p>x2 p9 Ø4x30</p> 	<p>x12 p38 Ø3.5x16</p> 
<p>x16 r1</p> 	<p>x16 r16</p> 	<p>x4 r23/1</p> 	<p>x4 r3</p> 
<p>x14 s2</p> 	<p>x1 lb L-350</p> 	<p>x1 z1</p> 	




1








2





3











4




5




6




7




8




9




10




11




12






13




14



15



16



17

